

Maintenance intervals for Porsche vehicles

07/2010

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Minor maintenance 1 (only 2008)*	Minor maintenance 2 (only 2008)*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter***	Spark plugs***	Air filter***	Brake fluid
Boxster/Boxster S Cayman/Cayman S (as of 2006)	2001–2004	every 20,000 km or every 2 years			every 40,000 km or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km or every 2 years	every 80,000 km or every 4 years	every 40,000 km or every 4 years	every 2 years
	2005-2007	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2008		every 20,000 km or every year	every 40,000 km or every 2 years	every 60,000 km or every 3 years		every 20,000 km or every year	every 60,000 km or every 4 years	every 60,000 km or every 3 years	every 2 years
	2009	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2001–2005	every 20,000 km or every 2 years			every 40,000 km or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km or every 2 years	every 80,000 km or every 4 years	every 40,000 km or every 4 years	every 2 years
Carrera/ Carrera S	2005–2007	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2008		every 20,000 km or every year	every 40,000 km or every 2 years	every 60,000 km or every 3 years		every 20,000 km or every year	every 60,000 km or every 4 years	every 60,000 km or every 3 years	every 2 years
	2009-2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
911 Turbo	2001–2004	every 20,000 km or every 2 years			every 40,000 km or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km or every 2 years	every 40,000 km	every 40,000 km or every 4 years	every 2 years
	2005–2007	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2008		every 20,000 km or every year	every 40,000 km or every 2 years	every 60,000 km or every 3 years		every 20,000 km or every year	every 40,000 km or every 4 years	every 60,000 km or every 3 years	every 2 years
	2009	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 45,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 45,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years

^{*}The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' in 2009.

**On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.

**In markets with reduced fuel quality it is possible that shortened maintenance intervals could occur concerning engine oil & oil filter, spark plugs and air filter as of MY 08. For further information please contact your Porsche Partner.

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Minor maintance 1 (only 2008)*	Minor maintance 2 (only 2008)*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter***	Spark plugs***	Air filter***	Brake fluid
Сауеппе	2003–2006	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km (or every year)/every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2008	every 30,000 km or every 2 years			every 60,000 km or every 4 years		fixed, max. 15,000 km or max. one year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2009	every 30,000 km or every 2 years			every 60,000 km or every 4 years		fixed, max. 15,000 km or max. one year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		fixed, max. 15,000 km or max. one year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2011	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every one year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
sel	2009	every 30,000 km or every 2 years			every 60,000 km or every 4 years		fixed, max. 15,000 km or max. one year		every 120,000 km or every 4 years	every 2 years
Cayenne Diesel	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		fixed, max. 15,000 km or max. one year		every 90,000 km or every 6 years	every 2 years
Ca)	2011	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every one year		every 90,000 km or every 6 years	every 2 years
	2003-2006	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
<u>ε</u>	2008		every 20,000 km or every year	every 40,000 km or every 2 years	every 60,000 km or every 3 years		every 20,000 km or every year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
Cayenne S Cayenne GTS	2009	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2011	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
Cayenne S Hybrid	2011	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every 1 year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years

^{*}The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

** On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.

*** In markets with reduced fuel quality it is possible that shortened maintenance intervals could occur concerning engine oil & oil filter, spark plugs and air filter as of MY 08. For further information please contact your Porsche Partner.

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Minor maintance 1 (only 2008)*	Minor maintance 2 (only 2008)*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter***	Spark plugs***	Air filter***	Brake fluid
	2003–2006	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
rbo so S	2008		every 20,000 km or every year	every 40,000 km or every 2 years	every 60,000 km or every 3 years		every 20,000 km or every year	every 40,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
Cayenne Turbo Cayenne Turbo S	2009	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 45,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
Cay	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 45,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2011	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 45,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
Panamera S Panamera 4S	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
Panamera Turbo	2010	every 30,000 km or every 2 years			every 60,000 km or every 4 years		every 15,000 km or every year	every 45,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years

^{*}The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

** On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.

*** In markets with reduced fuel quality it is possible that shortened maintenance intervals could occur concerning engine oil & oil filter, spark plugs and air filter as of MY 08. For further information please contact your Porsche Partner.