

PORSCHE

Intermediate maintenance (A markets*)

Macan

as of 2014 model

Vehicle Ident. No. _____

Work instruction
for order no.

☐ **Intermediate maintenance**

at 30000, 90000, 150000, 210000 km/20000, 60000, 100000, 140000 mls etc.

(Labour operation: 03 14 00..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Note: If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.



Electrics

Windscreen wiper/washer system, headlight cleaning system: check function

Horn: check function

Tyres: check tyre pressure (TPM)

Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval; read out soot mass in particle filter (Macan S Diesel only)

Inside the vehicle

Particle filter: replace filter element

Outside the vehicle

Check wiper blades

All headlights: check adjustment

Check and add reducing agent AdBlue® (Macan S Diesel only)

Under the vehicle

Drain engine oil, change oil filter (observe oil change service plan for the Macan/S Diesel)

Tyres and spare wheel: check condition

Brake lines: visual inspection for damage, routing and corrosion

Brake hoses: visual inspection for damage

Brake system: check brake pads and brake discs for wear (without removing wheels)

Drive shafts: visual inspection of the boots for leaks and damage

Cardan shaft: visual inspection of the rubber bellows for damage

Radiators and air intakes: visual inspection for external contamination and blockage

Engine compartment

Fill in engine oil

Coolant: check level and antifreeze

Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche

* For country allocation, see overview of A, B and C markets

PORSCHE

Intermediate maintenance (A markets*)

Macan

as of 2014 model

Vehicle Ident. No. _____

Work instruction
for order no.

--

☐ **Additional maintenance every 2 years**
(Labour operation: 03 51 00..)

Change brake fluid (use only original Porsche brake fluid)	
Prepare condition report for long-life guarantee	
Tyre sealing compound: check use-by date and replace if necessary	

☐ **Additional maintenance every 4 years**
(Labour operation: 03 52 00..)

Replace reducing agent AdBlue® (Macan S Diesel) (on vehicles with a mileage of less than 15,000 km/10,000 miles in four years)	
--	--

☐ **Additional maintenance for spark plugs**
every 60000 km / 40000 mls or every 6 years
(Labour operation: 03 81 00..)

Replace spark plugs	
---------------------	--

☐ **Additional maintenance every 90000 km / 60000 mls or every 6 years**
(Labour operation: 03 83 00..)

Air cleaner: replace filter element (Macan S Diesel)	
--	--

☐ **Additional maintenance every 240000km / 160000mls or every 16 years**
(Labour operation: 03 95 00..)

All-wheel final drive: change oil	
Rear final drive: change oil	

☐ **Additional maintenance every 60000km / 40000mls or every 6 years**
(Labour operation: 03 79 00..)

PDK transmission: change oil and filter	
---	--

☐ **Additional maintenance every 120000 km / 80000 mls or every 6 years**
(Labour operation: 03 85 00..)

Air cleaner: replace filter elements (Macan S/Turbo)	
--	--

Signature (mechanic): _____

Test drive:

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function	
Oils, fluids: visual inspection for leaks	

Signature (final check): _____

Porsche Centre