

PORSCHE

Maintenance (A markets*)

Macan

as of 2014 model

Vehicle Ident. No. _____

Work instruction
for order no.

☐ Maintenance

at 60000, 120000, 180000, 240000 km/40000, 80000, 120000, 160000 mls etc.

(Labour operation: 03 16 00..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Note: If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.



Electrics

Windscreen wiper/washer system, headlight cleaning system: check function

Horn: check function

Tyres: check tyre pressure (TPM)

Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval; read out soot mass in particle filter (Macan S Diesel only)

Inside the vehicle

Seat belts: check function and condition

Particle filter: replace filter element

Outside the vehicle

Check wiper blades

All headlights: check adjustment

Trailer hitch: check function

Tyres and spare wheel: check condition

Brake system: check brake pads and brake discs for wear

Brake hoses: visual inspection for damage

Radiators and air intakes: visual inspection for external contamination and blockage

Check and add reducing agent AdBlue® (Macan S Diesel only)

Under the vehicle

Underbody panels: visual inspection for completeness, secure installation and damage

Drain engine oil, change oil filter (observe oil change service plan for the Macan/S Diesel)

Visual inspection for leaks from underneath (oils and other fluids)

Brake lines: visual inspection for damage, routing and corrosion

Steering gear: visual inspection of the bellows for damage

Tie rod joints: check play and dust bellows

Drive shafts: visual inspection of the boots for leaks and damage

Cardan shaft: visual inspection of the rubber bellows for damage

Axle joints: check the play and visually inspect the dust boots for damage

Exhaust system: visual inspection for leaks and damage, check engine mount

Replace fuel filter (Macan S Diesel only)

Engine compartment

Fill in engine oil

Check drive belt (only if vehicle is used for off-road driving)

Fuel lines and connections: visual inspection

Visual inspection for leaks from above (oils and other fluids)

Coolant: check level and antifreeze

Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche

* For country allocation, see overview of A, B and C markets

as of 2014 model

Work instruction
for order no.

- (Labour operation: 03 51 00..)

Change brake fluid (use only original Porsche brake fluid)	
--	--

Prepare condition report for long-life guarantee	
--	--

Tyre sealing compound: check use-by date and replace if necessary	
---	--

- (Labour operation: 03 52 00..)

Replace reducing agent AdBlue® (Macan S Diesel) (on vehicles with a mileage of less than 15,000 km/10,000 miles in four years)	
--	--

- (Labour operation: 03 81 00..)

Replace spark plugs	
---------------------	--

- (Labour operation: 03 83 00..)

Air cleaner: replace filter element (Macan S Diesel)	
--	--

- (Labour operation: 03 95 00..)

All-wheel final drive: change oil	
-----------------------------------	--

Rear final drive: change oil	
------------------------------	--

- (Labour operation: 03 79 00..)

PDK transmission: change oil and filter	
---	--

- (Labour operation: 03 85 00..)

Air cleaner: replace filter elements (Macan S/Turbo)	
--	--

Signature (mechanic):

Test drive:

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function	
---	--

Oils, fluids: visual inspection for leaks	
---	--

Signature (final check):

Porsche Centre