

# PORSCHE

## Intermediate maintenance (C markets\*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) 911 Turbo (991) as of 2014 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction for order no.

- Intermediate maintenance**  
at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 miles etc.  
(Labour operation 03 14 00 ..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual  
Information: If the mileage for a regular service is not reached, maintenance must be carried out after 2, 6, 10..... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓

<b>Electrics</b>	
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory; reset maintenance interval	
<b>Inside the vehicle</b>	
Particle filter: replace filter element	
<b>Front luggage compartment</b>	
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	
Replace air intake pre-filter	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche	
<b>Outside the vehicle</b>	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)**	
Check wiper blades	
All headlights: check adjustment	
Radiators and air intakes: visual inspection for exterior soiling and blockage	
<b>Under the vehicle</b>	
Drain engine oil	
Change oil filter	
Tyres: check condition	
Brake lines: visual inspection for damage, routing and corrosion	
Brake hoses: visual inspection for damage	
Brake system: visual inspection of brake pads and brake discs for wear (without removing and fitting wheels)	
Drive shafts: visual inspection of the boots for leaks and damage	
<b>Engine compartment</b>	
Change oil filter	
Fill in engine oil	
Throttle housing: clean inside**	
Coolant: check level and antifreeze	
PDCC: check fluid level	

\* For country allocation, see overview of A, B and C markets  
\*\* Applies only for China

# PORSCHE

## Intermediate maintenance (C markets\*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) 911 Turbo (991) as of 2014 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction for order no.

**Additional maintenance for spark plugs**  
(Labour operation 03 81 00 ..)

		<input checked="" type="checkbox"/>
Replace spark plugs	every 30,000 km/18,000 mls or every 4 years	<input type="checkbox"/>
Replace spark plugs (911 Turbo only)	every 20,000 km/12,000 mls or every 4 years	<input type="checkbox"/>

**Additional maintenance for drive belt**  
(Labour operation 03 60 00 ..)

Check drive belt	at 60,000 km/36,000 mls or every 4 years	<input type="checkbox"/>
Check drive belt	at 150,000 km/90,000 mls or every 10 years	<input type="checkbox"/>
Check drive belt	at 240,000 km/144,000 mls or every 16 years	<input type="checkbox"/>

**Additional maintenance for convertible top**  
(Labour operation 03 70 00 ..)

Service and maintain convertible top	every 30,000 km/18,000 mls or every 2 years	<input type="checkbox"/>
--------------------------------------	---	--------------------------

**Additional maintenance every 90,000 km/54,000 mls or every 6 years**  
(Labour operation 03 83 00 ..)

Replace PDCC reservoir		<input type="checkbox"/>
Replace drive belt		<input type="checkbox"/>
Controlled all-wheel drive: change oil		<input type="checkbox"/>

**Additional maintenance every 120,000 km/72,000 mls or every 4 years**  
(Labour operation 03 85 00 ..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage		<input type="checkbox"/>
---	--	--------------------------

**Additional maintenance every 180,000 km/108,000 mls or every 12 years**  
(Labour operation 03 88 00 ..)

Manual transmission: change oil		<input type="checkbox"/>
All-wheel final drive: change oil		<input type="checkbox"/>
PDK transmission: change transmission oil		<input type="checkbox"/>
PDK transmission: change clutch fluid		<input type="checkbox"/>

**Every 2 years**  
(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)		<input type="checkbox"/>
Prepare condition report for long-life guarantee		<input type="checkbox"/>
Tyre sealing compound: Check use-by date and replace if necessary		<input type="checkbox"/>

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, PASM switch, Sport switch, sports exhaust system, door mirror fold-in function, heating, air conditioning and instruments: check function		<input type="checkbox"/>
Oils, fluids: visual inspection for leaks		<input type="checkbox"/>

Signature (final check): \_\_\_\_\_

Porsche Centre