

# PORSCHE

## Intermediate maintenance (China\*)

### Cayenne

### as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

**Intermediate maintenance**

**at 30000, 90000, 150000, 210000 km / 18000, 54000, 90000, 126000 miles etc.**

**(Labour operation: 03 14 00..)**

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

	✓
<b>Electrics</b>	
Windscreen wiper/washer system, headlight cleaning system: check function and nozzle settings	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval	
<b>Outside the vehicle</b>	
Check wiper blades	
All headlights: check adjustment	
Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)]	
<b>Under the vehicle</b>	
Drain engine oil	
Change oil filter	
Tyres and spare wheel: check condition	
Brake lines: visual inspection for damage, routing and corrosion	
Brake hoses: visual inspection for damage	
Brake system: check brake pads and brake discs for wear (without removing wheels)	
Drive shafts: visual inspection of the boots for leaks and damage	
Cardan shaft: visual inspection of the rubber bellows for damage	
Radiators and air intakes: visual inspection for external contamination and blockage	
<b>Engine compartment</b>	
Fill in engine oil	
Coolant: check level and antifreeze	
Check drive belt (only if vehicle is used for off-road driving)	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche	
PDCC and power steering: check fluid level	
Throttle housing: clean inside (China only)	

\* For country allocation, see overview of A, B and C markets

# PORSCHE

## Intermediate maintenance (China\*)

### Cayenne

### as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

--

**Additional maintenance every 2 years**  
(Labour operation: 03 51 00..)

Change brake fluid (use only original Porsche brake fluid)	
Clutch: change brake fluid; perform test and adaptation (Cayenne S E-Hybrid)	
Tyre sealing compound: check use-by date and replace if necessary	
Prepare condition report for long-life guarantee	

**Additional maintenance for spark plugs**  
(Labour operation: 03 81 00..)

Replace spark plugs every 20,000 km/12,000 miles or every 2 years	
---	--

**Additional maintenance every 120000 km / 72000 mls or every 4 years**  
(Labour operation: 03 85 00..)

Air cleaner: replace filter element (Cayenne V6/S/Turbo/S E-Hybrid)	
---	--

**Additional maintenance every 240000km / 144000mls or every 16 years**  
(Labour operation: 03 95 00..)

Rear final drive: change oil	
Tiptronic transmission: change ATF and ATF filter	
Transfer gear: change oil (Cayenne Diesel, S E-Hybrid, V6)	
All-wheel final drive: change oil	

**Additional maintenance every 90000 km / 54000 mls or every 6 years**  
(Labour operation: 03 83 00..)

Replace PDCC reservoir	
Air cleaner: replace filter element (Cayenne Diesel/S Diesel)	
Turbo compressor: replace drive belt (Cayenne 3.0 V6, S E-Hybrid)	

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Oils, fluids: visual inspection for leaks	
Remote control, front seats, electric parking brake and footbrake, engine, transmission, steering, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function	

Signature (final check): \_\_\_\_\_

Porsche Centre
----------------