

Major maintenance (China) Cayman (987), Cayman S (987) Boxster (987), Boxster S (987) 911 Carrera (997), 911 Carrera S (997)

Vehicle Ident. No.	Working instruction for order no.		
☐ Major maintenance at 60,000, 120,000, 180,000, 240,000 km etc. / 3 (Labour operation 03 26 00) For a description of the various models, see Techni		,000 miles etc.	
Note: If the mileage for a regular service is not reached	l, major maintenance must be ca	arried out after 4, 8, 12 years.	
The term 'checking' includes all necessary subsequent not include repairing, replacing and reconditioning parts		ting, correcting and topping up, but does	~
Mix fuel in the tank with additive (Keropur from Porsche Chinese sticker relating to fuel quality on the tank cap	; Part No. 000 043 206 89) and	check and if necessary affix additional	
Check spark plug change intervals in the Guarantee an			
Change engine oil and oil filter (please observe oil cha			
Vehicle underbody and engine compartment: visual insunderbody panels: visual inspection for completeness,			
Coolant hoses: check condition Radiators and air inlets: visual inspection for external co Coolant: check level and antifreeze			
Air cleaner: replace filter element			
Particle filter: replace filter element			
Fuel system: visual inspection for damage, routing and	secure fit of line connections		
Handbrake: check free play of handbrake lever			
Brake system: visual inspection of the brake pads and b	orake discs for wear		
Brake hoses and lines: visual inspection for leaks, dama	age, routing and corrosion		
Clutch: check pedal end position			
Steering gear: visual inspection of the bellows for dama Tie rod ends: check the play and dust boots	ge		
Axle joints: check the play and visually inspect the dust	boots for damage		
Check that the threaded connections of the running gea		ar are secure	

Check the door locks, lid locks and safety hooks of the front lid to ensure that they are secure and functioning properly

Windscreen wiper/washer system, headlight washer system: check fluid level and nozzle settings,

Continued overleaf

Horn: check operation

Copyright by
Dr. Ing. h. c. F. Porsche AG
After Sales Engineering
Printed in Germany - 06/08

Drive shafts: visual inspection of the boots for leaks and damage

Tyres: check condition and tyre pressure

Seat belts: check operation and condition

check antifreeze in winter months; check wiper blades

Battery: check functional state and fluid level
Replace spark plugs: see Additional maintenance

Electrical equipment, warning and indicator lights: check operation

Vehicle lighting: check operation All headlights: check adjustment

Exhaust system: visual inspection for leaks and damage, check engine mount



Major maintenance (China) Cayman (987), Cayman S (987) Boxster (987), Boxster S (987) 911 Carrera (997), 911 Carrera S (997)

Vehicle Ident. No	Working instruction for order no.		
☐ Additional maintenance for spark plugs			
(Labour operation 03 81 00)		· ·	
Replace spark plugs	every 30,000 km / 18,0	00 miles or every 4 years	
☐ Additional maintenance for drive belt (Labour operation 03 60 00)			
Check drive belt	every 60,000 km / 36,000 miles or every 4 years		
Check drive belt	every 150,000 km / 90,000 miles or every 10 years		
Check drive belt	every 240,000 km / 14	4,000 miles or every 16 years	
☐ Additional maintenance for convertible top (Labour operation 03 70 00)			
Service and maintain convertible top (911 Carrera only)	every 30,000 km / 18,0	000 miles or every 2 years	
□ Additional maintenance every 90,000 km / 54,000 (Labour operation 03 83 00) Replace drive belt	miles or every 6 years		
replace drive belt			
☐ Additional maintenance every 180,000 km / 108,0 (Labour operation 03 88 00)	00 miles or every 12 years	5	
Manual transmission: change oil			
Automatic transmission: change ATF and ATF filter			
Automatic transmission: change oil in final drive			
All-wheel final drive: change oil			
□ Every 2 years		T	_
File condition report for long-life guarantee			_
Change brake fluid			_
Check roll-over protection system (911 Carrera Cabriolet only)		
□ Every 4 veers			
□ Every 4 years			_
Replace tyre sealant			
☐ After 4 years, then every 2 years			
Check tyre pressure monitoring system battery			٦
check tyre proceded mornioning dystem battery			_
☐ After 4, 8, 10 years, then every 2 years			
Inspect airbag system			П
Ancillary unit mounts and suspension: visual inspection of all	rubber mounts for damage		
		-	
Signature (fitter):			
Test drive:	etuation traval) angina alutah	atopring transmission Dark Assist	_
Remote control, front seats, footbrake and handbrake (also acruise control, PSM switch, PASM switch, Sport switch, heating		_	
Oils, fluids: visual inspection for leaks	ig, an conditioning and instrum	ierits. Check operation	\dashv
One, naide. Visual inspection for leaks		I	_
Signature (final check):			
Copyright by			
Dr. Ing. h. c. F. Porsche AG	'	·	
After Sales Engineering			

Porsche Centre

Printed in Germany - 06/08