

PORSCHE

Major maintenance (China) Cayenne / S / GTS / Turbo As of 2008 model

Vehicle identification no. _____

Working instruction
for order no.

--

Major maintenance

At 60,000, 120,000, 180,000, 240,000 km / 36,000, 72,000, 108,000, 144,000 mls etc.
(Labour operation 03 26 00 ..)

For a description of the various models, see Technical Manual

Note: If the mileage for a regular service is not reached, major maintenance must be carried out after 4, 8, 12..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓

Mix fuel in the tank with additive (Keropur from Porsche; Part No. 000 043 206 89) and check and if necessary affix additional Chinese sticker relating to fuel quality on the tank cap	
Check spark plug change intervals in the Guarantee and Maintenance booklet and affix sticker if necessary (2008 model only)	
Vehicle underside and engine compartment: visual inspection for leaks (oils and other fluids): Engine compartment: visual inspection for damage; underbody covers: visual inspection for completeness, installation and damage	
Replace engine oil and oil filter (the oil change service plan applies for the Cayenne)	
PDCC: check fluid level	
Particle filter: replace filter element	
Check drive belt	
Steering gear: Visually inspect the bellows for damage; tie rod ends: check the play and dust boots	
Power steering: check fluid level	
Fuel lines and connections: visual inspection	
Radiators and air inlets: Visual inspection for external soiling and blockage Coolant: check level and antifreeze	
Foot-operated parking brake: check free play	
Brake system: visual inspection of brake pads and discs for wear	
Brake hoses and lines: visual inspection for damage, routing and corrosion	
Drive shafts: visual inspection of the boots for leaks and damage	
Axle joints: check the play and visually inspect the dust boots for damage	
Exhaust system: visual inspection for leaks and damage, check engine mount	
Tyres, emergency spare wheel and external spare wheel: check condition and tyre pressure	
Lubricate door arrester and fastening pins	
Panorama roof system: teach control unit	
Windscreen wiper/washer system, headlight washer system: check operation, fluid level and nozzle settings, pay attention to antifreeze protection in winter months; check wiper blades	
Seat belts: check function and condition	
All headlights: check setting; horn: check function	
Battery and vent hoses: check functional state and fluid level	
Trailer hitch: check function	
Airbag system: check operation and condition (see Additional maintenance)	

Continued overleaf

PORSCHE

Major maintenance (China) Cayenne / S / GTS / Turbo As of 2008 model

Vehicle identification no. _____

Working instruction
for order no.

--

Additional maintenance, replacing spark plugs
(Labour operation 03 81 00 ..)

Replace spark plugs - Cayenne	every 60,000 km / 36,000 miles or every 4 years	
Replace spark plugs - Cayenne S / GTS	every 30,000 km / 18,000 miles or every 4 years	
Replace spark plugs - Cayenne Turbo	every 20,000 km / 12,000 miles or every 4 years	

Additional maintenance every 90,000 km / 54,000 miles or every 6 years
(Labour operation 03 83 00 ..)

Replace PDCC reservoir	
------------------------	--

Additional maintenance every 120,000 km / 72,000 miles or every 4 years
(Labour operation 03 85 00 ..)

Air cleaner: replace filter element	
-------------------------------------	--

Additional maintenance every 240,000 km / 144,000 miles or every 16 years
(Labour operation 03 95 00 ..)

All-wheel final drive: change oil	
Rear final drive: change oil	
Transfer box: change oil	
Manual transmission: change oil	
Tiptronic transmission: change ATF and ATF filter	

Every 2 years

Change brake fluid (use only original Porsche brake fluid)	
File condition report for long-life guarantee	

Every 4 years

Replace tyre sealant	
----------------------	--

After 4 years, then every 2 years

Check Tire Pressure Monitoring system battery	
---	--

After 10 years, then every 2 years

Airbag system: check operation and condition (see Major maintenance)	
--	--

Signature (fitter): _____

Test drive:

Remote control, front seats, foot and parking brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning system and instruments: check for correct functioning	
Oils, fluids: visual inspection for leaks	

Signature (final check): _____