

Oil maintenance (B markets*) Panamera / S / Turbo / S / E-Hybrid / S E-Hybrid / Panamera Diesel / S Diesel as of 2017 model

Name		Date						
Licence No.		Mileage						
Vehicle Ident. No.		Order No.:						
Oil maintenance		According to fixed service interval indicator, at the latest after 15,000 km/10,000 mls or 1 year.						
Note		If the mileage for the oil change is not reached, an oil change must be carried out after one ye the latest. The term 'checking' includes all necessary subsequent work, such as adjustments, readjustments and corrections, but does not include repairs, replacements or overhaul of parts or assemblies. Measures	ar at	Panamera / S / Turbo / S / E-Hybrid / S E-Hybrid	Panamera Diesel / S Diesel	Every 15 tkm/10 tmls or 1 year		
	Oil maintanance	Drain engine oil		•	•			
		Change oil filter		•	•			
		Underbody panels: visual inspection for completeness, secure installation and damage		•	•			
		Visual inspection for leaks from underneath (oils and other fluids)		•	•			
		Tyres: check condition		•	•			
		Brake lines: visual inspection for damage, routing and corrosion		•	•			
		Brake hoses: visual inspection for damage		•	•			
		Fill in engine oil		•	•			
		Drain water from fuel filter (V6 Diesel EU5+ only, I-no. 7MJ)			•			
		Emergency call system ERA-GLONASS: check battery charge state (Eurasian customs union or	ıly)	•	•			
		Check and add reducing agent AdBlue®			•			
		Reset maintenance interval		•	•			

^{*} For country allocation, see overview of A, B and C markets

Carry out depending on mileage/age (Please tick)

Relevant model line



Oil maintenance (B markets*) Panamera / S / Turbo / S / E-Hybrid / S E-Hybrid / Panamera Diesel / S Diesel as of 2017 model

Signature (mechanic):	-	

Stamp Porsche Centre

 $^{^{\}star}$ For country allocation, see overview of A, B and C markets

Carry out depending on mileage/age (Please tick)

Relevant model line