

# PORSCHE

## Intermediate maintenance (China\*)

### 911 (991)

### as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

**Intermediate maintenance**

**at 30000, 90000, 150000, 210000 km / 18000, 54000, 90000, 126000 miles etc.**

**(Labour operation: 03 14 00..)**

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

<b>Electrics</b>	✓
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory; reset maintenance interval	
Check actuator travel of brake shoes (Turbo / Turbo S only)	
<b>Inside the vehicle</b>	
Particle filter: replace filter element	
<b>Luggage compartment</b>	
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	
Replace air intake pre-filter	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche	
<b>Outside the vehicle</b>	
Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)]	
Check wiper blades	
All headlights: check adjustment	
Radiators and air intakes: visual inspection for external contamination and blockage	
<b>Under the vehicle</b>	
Drain engine oil	
Tyres: check condition	
Brake lines: visual inspection for damage, routing and corrosion	
Brake hoses: visual inspection for damage	
Brake system: check brake pads and brake discs for wear (without removing wheels)	
Drive shafts: visual inspection of the boots for leaks and damage	
<b>Engine compartment</b>	
Change oil filter	
Fill in engine oil	
Throttle housing: clean inside (China only)	
Coolant: check level and antifreeze	
PDCC: check fluid level	

\* For country allocation, see overview of A, B and C markets

# PORSCHE

## Intermediate maintenance (China\*)

911 (991)

as of 2015 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

--

**Additional maintenance every 2 years**  
(Labour operation: 03 51 00..)

Change brake fluid (use only original Porsche brake fluid)	
Prepare condition report for long-life guarantee	
Tyre sealing compound: check use-by date and replace if necessary	

**Additional maintenance for drive belt**  
(Labour operation: 03 60 00..)

Check drive belt, at 60,000 km/40,000 miles or every 4 years	
Check drive belt, at 150,000 km/100,000 miles or every 10 years	
Check drive belt, at 240,000 km/160,000 miles or every 16 years	

**Additional maintenance for convertible top**  
**every 30000 km / 18000 mls or every 2 years**  
(Labour operation: 03 70 00..)

Service and maintain convertible top	
--------------------------------------	--

**Additional maintenance for spark plugs**  
**every 20000 km / 12000 mls or every 2 years**  
(Labour operation: 03 81 00..)

Replace spark plugs	
---------------------	--

**Additional maintenance every 90000 km / 54000 mls or every 4 years**  
(Labour operation: 03 83 00..)

Replace PDCC reservoir	
Replace drive belt	
Controlled all-wheel drive: change oil	

**Additional maintenance every 120000 km / 72000 mls or every 4 years**  
(Labour operation: 03 85 00..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage	
---	--

**Additional maintenance every 180000 km / 108000 mls or every 12 years**  
(Labour operation: 03 88 00..)

Manual transmission: change oil	
All-wheel final drive: change oil	
PDK transmission: change transmission oil	
PDK transmission: change clutch fluid	

**Additional maintenance for mobile roofs**  
**every 30000 km / 18000 mls or every 2 years**  
(Labour operation: 03 71 00..)

Service and maintain Targa roof	
---------------------------------	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, PASM switch, Sport switch, sports exhaust system, door mirror fold-in function, heating, air conditioning and instruments: check function	
Oils, fluids: visual inspection for leaks	

Signature (final check): \_\_\_\_\_


Porsche Centre