

# PORSCHE

## Intermediate maintenance (C markets\*)

### 911 GT3 (991)

### as of 2014 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

**Intermediate maintenance**

**at 20000, 60000, 100000, 140000 km / 12000, 36000, 60000, 84000 miles etc.**

**(Labour operation: 03 14 00..)**

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

	✓
<b>Electrics</b>	
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory; reset maintenance interval	
<b>Inside the vehicle</b>	
Particle filter: replace filter element	
<b>Luggage compartment</b>	
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	
Replace air intake pre-filter	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche	
<b>Outside the vehicle</b>	
Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)]	
Check wiper blades	
All headlights: check adjustment	
Radiators and air intakes: visual inspection for external contamination and blockage	
Check central lock on wheels	
<b>Under the vehicle</b>	
Drain engine oil	
Change oil filter	
Tyres: check condition	
Brake lines: visual inspection for damage, routing and corrosion	
Brake hoses: visual inspection for damage	
Brake system: check brake pads and brake discs for wear	
Drive shafts: visual inspection of the boots for leaks and damage	
Rear-axle steering: check bellows, dust boots and play on joints	
Check that threaded connections for chassis adjustment at front and rear are secure	
Check vehicle height	
Control boxes for exhaust flaps: check function	
<b>Engine compartment</b>	
Fill in engine oil	
Coolant: check level and antifreeze	

\* For country allocation, see overview of A, B and C markets

# PORSCHE

## Intermediate maintenance (C markets\*) 911 GT3 (991) as of 2014 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction  
for order no.

--

**Additional maintenance every 2 years**  
(Labour operation: 03 51 00..)

Change brake fluid (use only original Porsche brake fluid)	
Prepare condition report for long-life guarantee	
Tyre sealing compound: check use-by date and replace if necessary	

**Additional maintenance for spark plugs**  
every 20000 km / 12000 miles or every year  
(Labour operation: 03 81 00..)

Replace spark plugs	
---------------------	--

**Additional maintenance every 80000 km / 48000 mls or every 6 years**  
(Labour operation: 03 82 00..)

PDK transmission: change clutch fluid	
---------------------------------------	--

**Additional maintenance every 120000 km / 72000 mls or every 4 years**  
(Labour operation: 03 85 00..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage	
---	--

**Additional maintenance every 160000km / 96000mls or every 12 years**  
(Labour operation: 03 86 00..)

PDK transmission: change transmission oil	
---	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, PDK Sport switch, Lift switch, sports exhaust system, heating, air conditioning and instruments: check function	
Oils, fluids: visual inspection for leaks	

Signature (final check): \_\_\_\_\_

	Porsche Centre