

PORSCHE

Intermediate maintenance (C markets*) 911 GT3 RS 4.0 (997) as of 2011 model

Vehicle Ident. No. _____

Working instruction for
order no.

--

- Intermediate maintenance**
at 20,000, 60,000, 100,000, 140,000 km/12,000, 36,000, 60,000, 84,000 miles etc.
(Labour operation 03 14 00 ..)
For a description of the various models, see Technical Manual

Note: If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.



Diagnostic system: read out fault memory; reset maintenance interval	
Change engine oil and oil filter (please observe oil change service plan for the 911 GT3)	
Vehicle underbody and engine compartment: visual inspection for leaks (oils and fluids) and chafing damage (lines and hoses) Underbody panels: visual inspection for completeness, secure installation and damage	
Coolant hoses: check condition Radiators and air inlets: visual inspection for external contamination and blockage Coolant: check level and antifreeze	
Air cleaner: replace filter element	
Particle filter: replace filter element	
Brake hoses and lines: visual inspection for leaks, damage, routing and corrosion	
Drive shafts: visual inspection of the boots for leaks and damage	
Replace rear-axle anti-roll-bar mount	
Tyres: check condition and tyre pressure	
Check the door locks, lid locks and safety hooks of the front lid to ensure that they are secure and functioning properly	
Vehicle lighting: check operation All headlights: check adjustment Horn: check operation	
Windscreen wiper/washer system, headlight cleaning system: check fluid level and nozzle settings, check antifreeze in winter months; check wiper blades	
Electrical equipment, warning and indicator lights: check operation	
Battery: check functional state and fluid level	
Replace spark plugs: see Additional maintenance	

* For country allocation, see overview of A, B and C markets
Continued overleaf

PORSCHE

Intermediate maintenance (C markets) 911 GT3 RS 4.0 (997) as of 2011 model

Vehicle Ident. No. _____

Working instruction for
order no.

--

Additional maintenance for spark plugs
(Labour operation 03 81 00 ..)

Replace spark plugs 911 GT3	every 20,000 km/12,000 miles or every 2 years	
-----------------------------	---	--

Additional maintenance every 160,000 km/96,000 miles or every 12 years
(Labour operation 03 86 00 ..)

Manual transmission: change oil	
---------------------------------	--

Every 2 years

Change brake fluid	
--------------------	--

Every 4 years

Replace tyre sealant	
----------------------	--

After 4 years, then every 2 years

Check Tyre Pressure Monitoring system battery	
---	--

After 4, 8, 10 years, then every 2 years

Visual inspection of airbag units	
-----------------------------------	--

Ancillary unit mounts and suspension: visual inspection of all rubber mountings and boots for damage	
--	--

Signature (mechanic): _____

Test drive:

Remote control, front seats, footbrake and handbrake (also actuation travel), engine, clutch, steering, transmission, cruise control, TC switch, PASM switch, Sport switch, heating, air conditioning and instruments: check operation	
--	--

Oils, fluids: visual inspection for leaks	
---	--

Signature (final check): _____