

# PORSCHE

## Intermediate maintenance (China only) Cayenne/S/GTS/Turbo/Turbo S as of 2010 model

Vehicle Ident. No. \_\_\_\_\_

Working  
instruction for  
order no.

--

**Intermediate maintenance**

**At 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 miles etc.  
(Labour operation 03 14 00 ..)**

For a description of the various models, see Technical Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓
---

Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)	
Diagnostic system: read out fault memory; reset maintenance interval	
Change engine oil and oil filter (please observe oil change service plan for the Cayenne)	
PDCC: check fluid level	
Check drive belt (only if vehicle is used for off-road driving)	
Radiators and air intakes: visual inspection for external contamination and blockage Check coolant level	
Brake system: visual inspection of brake pads and brake discs for wear (without removing and fitting wheels)	
Brake hoses and lines: visual inspection for damage, routing and corrosion	
Drive shafts: visual inspection of the boots for leaks and damage	
Tyres, emergency spare wheel and external spare wheel: check condition and tyre pressure	
Windscreen wiper/washer system, headlight cleaning system: check fluid level and nozzle settings; check window cleaner and antifreeze, depending on the season; check wiper blades	
All headlights: check setting; horn: check operation	
Battery and vent hoses: check functional state and fluid level	

Continued overleaf

# PORSCHE

## Intermediate maintenance (China only) Cayenne/S/GTS/Turbo/Turbo S as of 2010 model

Vehicle Ident. No. \_\_\_\_\_

Working  
instruction for  
order no.

--

**Additional maintenance, replacing spark plugs**  
(Labour operation 03 81 00 ..)

Replace spark plugs - Cayenne	every 60,000 km/36,000 miles or every 4 years	✓
Replace spark plugs - Cayenne S/GTS	every 30,000 km/18,000 miles or every 4 years	
Replace spark plugs - Cayenne Turbo/S	every 20,000 km/12,000 miles or every 4 years	

**Additional maintenance every 90,000 km/54,000 miles or every 6 years**  
(Labour operation 03 83 00 ..)

Replace PDCC reservoir	
------------------------	--

Air cleaner: replace filter element (Cayenne Diesel only)

**Additional maintenance every 120,000 km/72,000 miles or every 6 years**  
(Labour operation 03 85 00 ..)

Air cleaner: replace filter element (not for the Cayenne Diesel)	
--	--

**Additional maintenance every 240,000 km/144,000 miles or every 16 years**  
(Labour operation 03 95 00 ..)

All-wheel final drive: change oil	
Rear final drive: change oil	
Transfer gear: change oil	
Manual transmission: change oil	
Tiptronic transmission: change ATF and ATF filter	

**Every 2 years**  
(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)	
File condition report for long-life guarantee	

**Every 4 years**  
(Labour operation 03 52 00 ..)

Replace tyre sealing compound	
-------------------------------	--

**After 4, 8, 10 years, then every 2 years**  
(Labour operation 03 54 00 ..)

Visual inspection of airbag units (see Additional maintenance)	
--	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, foot and parking brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: check operation	
Oils, fluids: visual inspection for leaks	

Signature (final check): \_\_\_\_\_