

# PORSCHE

## Intermediate maintenance (C markets\*) Cayenne (V6) / S / GTS / Turbo / Diesel / S Diesel / S Hybrid As of model year 2012

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Intermediate maintenance**

at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 mls etc.

(Labour operation 03 14 00 ..)

For a description of the various models, see Technical Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓
---

<b>Electrics</b>	
Windscreen wiper/washer system, headlight washer: Check function and nozzle settings	
Horn: Check function	
Tyres and spare wheel: Check tyre pressure	
Diagnostic system: Read out fault memory and transfer gear wear integrator; reset maintenance interval; Read out soot mass particle filter (Cayenne Diesel / S Diesel only)	
<b>Outside the vehicle</b>	
Check wiper blades	
All headlights: Check adjustment	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89) **	
<b>Under the vehicle</b>	
Drain engine oil, change oil filter (observe oil change service plan for all Cayenne models)	
Tyres and spare wheel: Check condition	
Brake lines: Visual inspection for damage, correct routing and corrosion	
Brake hoses: Visual inspection for damage	
Brake system: Visual inspection of brake pads and brake discs for wear (without removing and fitting wheels)	
Drive shafts: Visual inspection of the boots for leaks and damage	
Cardan shaft: Visual inspection of the rubber bellows for damage	
Radiators and air intakes: Visual inspection for external soiling and blockage	
<b>Engine compartment</b>	
Fill in engine oil (observe oil change service plan for all Cayenne models)	
Replace fuel filter (Cayenne Diesel / S Diesel only)	
Coolant: Check level and antifreeze	
Check drive belt (only if vehicle is used for off-road driving)	
Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season, use Porsche approved windscreen cleaner only	
PDCC: Check fluid level	
Throttle housing: clean inside **	

\* For country allocation, see Overview of C markets

\*\* Applies only for China

Continued overleaf

# PORSCHE

## Intermediate maintenance (C markets\*) Cayenne (V6) / S / GTS / Turbo / Diesel / S Diesel / S Hybrid As of model year 2012

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Additional maintenance, replacing spark plugs**

(Labour operation 03 81 00 ..)

✓
---

Replace spark plugs - Cayenne 3.0 V6 / S Hybrid	every 20,000 km/12,000 mls or every 4 years	
Replace spark plugs - Cayenne (V6)	every 60,000 km/36,000 mls or every 4 years	
Replace spark plugs - Cayenne S / GTS	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs - Cayenne Turbo	every 20,000 km/12,000 mls or every 4 years	

**Additional maintenance every 90,000 km/54,000 mls or every 6 years**

(Labour operation 03 83 00 ..)

Replace PDCC reservoir	
Air cleaner: Replace air-cleaner element (Cayenne Diesel / S Diesel)	
Turbo compressor: Replace drive belt (Cayenne 3.0 V6, S Hybrid)	

**Additional maintenance every 120,000 km/72,000 mls or every 4 years**

(Labour operation 03 85 00 ..)

Air cleaner: Replace air-cleaner element (Cayenne (V6), S, GTS, Turbo, S Hybrid)	
--	--

**Additional maintenance every 240,000 km/144,000 mls or every 16 years**

(Labour operation 03 95 00 ..)

All-wheel final drive: Change oil	
Rear final drive: Change oil	
Transfer gear (Cayenne Diesel, S Hybrid, V6): Change oil	
Manual transmission: Change oil	
Tiptronic transmission: Change ATF and ATF filter	

**Every 2 years**

(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)	
Complete Condition Report for Long-Life Guarantee	
Clutch: Change brake fluid; perform test and adaptation (Cayenne S Hybrid only)	

**Every 4 years**

(Labour operation 03 52 00 ..)

Replace tyre sealant	
----------------------	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: Check function	
Oils, fluids: Visual inspection for leaks	

Signature (final check): \_\_\_\_\_