

Intermediate maintenance (C markets*) Boxster / S (981), Cayman / S (981) as of 2014 model

	Work instruction for	
Vehicle Ident. No.	order no.	

□ Intermediate maintenance

at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 miles etc.	
(Labour operation 03 14 00)	

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Information: If the mileage for a regular service is not reached, maintenance must be carried out after 2, 6, 10...... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

Electrics			
Windscreen wiper/washer system, headlight cleaning system: check function			
Horn: check function			
Tyres: check tyre pressure (TPM)			
Diagnostic system: read out fault memory; reset maintenance interval			
Inside the vehicle			
Particle filter: replace filter element			
Front luggage compartment			
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly			
Replace air intake pre-filter			
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use			
windscreen cleaners approved by Porsche			
Outside the vehicle			
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)**			
Check wiper blades			
All headlights: check adjustment			
Radiators and air intakes: visual inspection for exterior soiling and blockage			
Under the vehicle			
Drain engine oil			
Change oil filter			
Tyres: check condition			
Brake lines: visual inspection for damage, routing and corrosion			
Brake hoses: visual inspection for damage			
Brake system: visual inspection of brake pads and brake discs for wear (without removing and fitting wheels)			
Drive shafts: visual inspection of the boots for leaks and damage			
Rear luggage compartment			
Fill in engine oil			
Coolant: check level and antifreeze			

* For country allocation, see overview of A, B and C markets

** Applies only for China



Intermediate maintenance (C markets*) Boxster / S (981), Cayman / S (981) as of 2014 model

Vehicle Ident. No	Work instruction for order no.			
□ Additional maintenance for spark plugs		_		
(Labour operation 03 81 00)		✓		
Replace spark plugs	every 30,000 km/18,	000 mls or every 4 years		
Additional maintenance for drive belt				
(Labour operation 03 60 00)				
Check drive belt	at 60,000 km/36,000	mls or every 4 years		
Check drive belt	at 150,000 km/90,000 mls or every 10 years			
Check drive belt	eck drive belt at 240,000 km/144,000 mls or every 16 years			
 Additional maintenance every 90,000 km/54,00 (Labour operation 03 83 00) 	0 mls or every 6 years			
Replace drive belt				
□ Additional maintenance every 120,000 km/72,0 (Labour operation 03 85 00)	00 mls or every 4 years			
Ancillary unit mounts and chassis: visual inspection of all re-	ubber mountings and boots for	damage		
□ Additional maintenance every 180,000 km/108,	000 mls or every 12 years			
(Labour operation 03 88 00)				
Manual transmission: change oil				
PDK transmission: change transmission oil				
PDK transmission: change clutch fluid				
Every 2 years				
(Labour operation 03 51 00)				
Change brake fluid (use only original Porsche brake fluid)				
Prepare condition report for long-life guarantee				
Tyre sealing compound: Check use-by date and replace if necessary				
Signature (mechanic):				
Toot drives				
Test drive:	harden (alen entretien (
Remote control, front seats, electric parking brake and fool		0		

Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, PASM switch, Sport switch, sports exhaust system, door mirror fold-in function, heating, air conditioning and instruments: check function Oils, fluids: visual inspection for leaks

Signature (final check): _____

Porsche Centre