

# PORSCHE

## Intermediate maintenance (C markets\*) Panamera / S / GTS / Turbo / Diesel / S E-Hybrid As of model year 2014

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Intermediate maintenance**

at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 mls etc.  
(Labour operation 03 14 00 ..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after two years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓
---

<b>Electrics</b>	
Windscreen wiper/washer system, headlight washer: Check function and nozzle settings	
Horn: Check function	
Tyres and spare wheel: Check tyre pressure	
Diagnostic system: Read out fault memory; reset maintenance interval; Read out soot mass particle filter (Panamera Diesel only)	
<b>Inside the vehicle</b>	
Particle filter: Replace filter element	
<b>Outside the vehicle</b>	
Check wiper blades	
All headlights: Check adjustment	
Battery vent hose: Check condition	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89) **	
<b>Under the vehicle</b>	
Drain engine oil, change oil filter (observe oil change service plan)	
Tyres and spare wheel: Check condition	
Replace fuel filter (Panamera Diesel only)	
Brake lines: Visual inspection for damage, correct routing and corrosion	
Brake hoses: Visual inspection for damage	
Brake system: Visual inspection of brake pads and brake discs for wear	
Drive shafts: Visual inspection of the boots for leaks and damage	
Radiators and air intakes: Visual inspection for external soiling and blockage	
<b>Engine compartment</b>	
Top up engine oil (observe oil change service plan)	
Coolant: Check level and antifreeze	
Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season; use Porsche approved windscreen cleaner only	
PDCC and power steering: Check fluid level	
Throttle housing: clean inside **	

\* For country allocation, see overview of A, B and C markets

\*\* Applies only for China

Continued overleaf

# PORSCHE

## Intermediate maintenance (C markets\*) Panamera / S / GTS / Turbo / Diesel / S E-Hybrid As of model year 2014

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Additional maintenance, replacing spark plugs**  
(Labour operation 03 81 00 ..)

Replace spark plugs - Panamera (3.0 V6)	every 20,000 km/12,000 mls or every 4 years	✓
Replace spark plugs - Panamera (3.6 V6) / GTS	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs - Panamera S	every 20,000 km/12,000 mls or every 4 years	
Replace spark plugs - Panamera Turbo	every 20,000 km/12,000 mls or every 4 years	
Replace spark plugs - Panamera S E-Hybrid	every 20,000 km/12,000 mls or every 4 years	

**Additional maintenance every 90,000 km/54,000 mls or every 4 years**  
(Labour operation 03 83 00 ..)

Replace PDCC reservoir	
PDK transmission: Change oil (Panamera / S / GTS / Turbo)	
Turbo compressor: Replace drive belt (Panamera S E-Hybrid)	
Air cleaner: Replace filter element (Panamera / S / Turbo / Diesel / E-Hybrid)	
Air cleaner/additional air filter: replace filter elements (Panamera GTS)	

**Additional maintenance every 180,000 km/108,000 mls or every 12 years**  
(Labour operation 03 88 00 ..)

All-wheel final drive: Change oil	
Rear final drive: Change oil	

**Additional maintenance every 240,000 km/144,000 mls or every 16 years**  
(Labour operation 03 95 00 ..)

Automatic transmission: change ATF and ATF filter (Panamera Diesel / S E-Hybrid)	
--	--

**Every 2 years**  
(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)	
Complete Condition Report for Long-Life Guarantee	
Clutch: Change brake fluid; perform test and adaptation (Panamera S E-Hybrid)	
Tyre sealing compound: Check use-by date and replace if necessary	

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: Check function	
Oils, fluids: Visual inspection for leaks	

Signature (final check): \_\_\_\_\_

\* For country allocation, see overview of A, B and C markets