

PORSCHE

Intermediate maintenance (China) Panamera / S / GTS / Turbo / Diesel / S E-Hybrid As of model year 2015

Vehicle Ident. No. _____

Working instruction
for order no.

| |
|--|
| |
|--|

Intermediate maintenance

at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 mls etc.
(Labour operation 03 14 00 ..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Note: If the mileage for a regular service is not reached, intermediate maintenance must be carried out after two years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

| |
|---|
| ✓ |
|---|

| | |
|---|--|
| Electrics | |
| Windscreen wiper/washer system, headlight washer: Check function and nozzle settings | |
| Horn: Check function | |
| Tyres and spare wheel: Check tyre pressure | |
| Diagnostic system: Read out fault memory; reset maintenance interval; Read out soot mass particle filter (Panamera Diesel only) | |
| Inside the vehicle | |
| Particle filter: Replace filter element | |
| Outside the vehicle | |
| Check wiper blades | |
| All headlights: Check adjustment | |
| Battery vent hose: Check condition | |
| Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89) | |
| Under the vehicle | |
| Drain engine oil, change oil filter (observe oil change service plan) | |
| Tyres and spare wheel: Check condition | |
| Replace fuel filter (Panamera Diesel only) | |
| Brake lines: Visual inspection for damage, correct routing and corrosion | |
| Brake hoses: Visual inspection for damage | |
| Brake system: Visual inspection of brake pads and brake discs for wear | |
| Drive shafts: Visual inspection of the boots for leaks and damage | |
| Radiators and air intakes: Visual inspection for external soiling and blockage | |
| Engine compartment | |
| Top up engine oil (observe oil change service plan) | |
| Coolant: Check level and antifreeze | |
| Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season; use Porsche approved windscreen cleaner only | |
| PDCC and power steering: Check fluid level | |
| Throttle housing: clean inside | |

Continued overleaf

PORSCHE

Intermediate maintenance (China) Panamera / S / GTS / Turbo / Diesel / S E-Hybrid As of model year 2015

Vehicle Ident. No. _____

Working instruction
for order no.

| |
|--|
| |
|--|

Additional maintenance, replacing spark plugs
(Labour operation 03 81 00 ..)

| | | |
|---------------------|---|---|
| Replace spark plugs | every 20,000 km/12,000 mls or every 2 years | ✓ |
|---------------------|---|---|

Additional maintenance every 90,000 km/54,000 mls or every 4 years
(Labour operation 03 83 00 ..)

| | | |
|--|--|--|
| Replace PDCC reservoir | | |
| PDK transmission: Change oil (Panamera / S / GTS / Turbo) | | |
| Turbo compressor: Replace drive belt (Panamera S E-Hybrid) | | |
| Air cleaner: Replace filter element (Panamera / S / Turbo / Diesel / E-Hybrid) | | |
| Air cleaner/additional air filter: replace filter elements (Panamera GTS) | | |

Additional maintenance every 180,000 km/108,000 mls or every 12 years
(Labour operation 03 88 00 ..)

| | | |
|-----------------------------------|--|--|
| All-wheel final drive: Change oil | | |
| Rear final drive: Change oil | | |

Additional maintenance every 240,000 km/144,000 mls or every 16 years
(Labour operation 03 95 00 ..)

| | | |
|--|--|--|
| Automatic transmission: change ATF and ATF filter (Panamera Diesel / S E-Hybrid) | | |
|--|--|--|

Every 2 years
(Labour operation 03 51 00 ..)

| | | |
|---|--|--|
| Change brake fluid (use only original Porsche brake fluid) | | |
| Complete Condition Report for Long-Life Guarantee | | |
| Clutch: Change brake fluid; perform test and adaptation (Panamera S E-Hybrid) | | |
| Tyre sealing compound: Check use-by date and replace if necessary | | |

Signature (mechanic): _____

Test drive:

| | | |
|--|--|--|
| Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: Check function | | |
| Oils, fluids: Visual inspection for leaks | | |

Signature (final check): _____