

PORSCHE

Intermediate maintenance (C markets*) Panamera / S / GTS / Turbo / Diesel / S Hybrid As of model year 2012

Vehicle Ident. No. _____

Working instruction
for order no.

--

- Intermediate maintenance**
at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 mls etc.
(Labour operation 03 14 00 ..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Note: If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

	✓
Electrics	
Windscreen wiper/washer system, headlight washer: Check function and nozzle settings	
Horn: Check function	
Tyres and spare wheel: Check tyre pressure	
Diagnostic system: Read out fault memory; reset maintenance interval; Read out soot mass particle filter (Panamera Diesel only)	
Inside the vehicle	
Particle filter: Replace filter element	
Outside the vehicle	
Check wiper blades	
All headlights: Check adjustment	
Clean reversing camera	
Battery vent hose: Check condition	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89) **	
Under the vehicle	
Drain engine oil, change oil filter (observe oil change service plan)	
Tyres and spare wheel: Check condition	
Replace fuel filter (Panamera Diesel only)	
Brake lines: Visual inspection for damage, correct routing and corrosion	
Brake hoses: Visual inspection for damage	
Brake system: Visual inspection of brake pads and brake discs for wear	
Drive shafts: Visual inspection of the boots for leaks and damage	
Radiators and air intakes: Visual inspection for external soiling and blockage	
Engine compartment	
Top up engine oil (observe oil change service plan)	
Coolant: Check level and antifreeze	
Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season; use Porsche approved windscreen cleaner only	
PDCC and power steering: Check fluid level	
Throttle housing: clean inside**	

* For country allocation, see overview of A, B and C markets

** Applies only for China

Continued overleaf

PORSCHE

Intermediate maintenance (C markets) Panamera / S / GTS / Turbo / Diesel / S Hybrid As of model year 2012

Vehicle Ident. No. _____

Working instruction
for order no.

--

Additional maintenance, replacing spark plugs

(Labour operation 03 81 00 ..)

Replace spark plugs - Panamera	every 30,000 km/18,000 mls or every 4 years	✓
Replace spark plugs - Panamera S / GTS	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs - Panamera Turbo	every 20,000 km/12,000 mls or every 4 years	
Replace spark plugs - Panamera S Hybrid	every 20,000 km/12,000 mls or every 4 years	

Additional maintenance every 90,000 km/54,000 mls or every 4 years

(Labour operation 03 83 00 ..)

Replace PDCC reservoir	
PDK transmission: Change oil (Panamera / S / GTS / Turbo)	
Turbo compressor: Replace drive belt (Panamera S Hybrid)	
Air cleaner: Replace filter element (Panamera / S / Turbo / Diesel / Hybrid)	
cleaner/additional air filter: replace filter elements (Panamera GTS)	

Additional maintenance every 180,000 km/108,000 mls or every 12 years

(Labour operation 03 88 00 ..)

Manual transmission: Change oil	
All-wheel final drive: Change oil	
Rear final drive: Change oil	

Additional maintenance every 240,000 km/144,000 mls or every 16 years

(Labour operation 03 95 00 ..)

Automatic transmission: change ATF and ATF filter (Panamera Diesel / S Hybrid)	
--	--

Every 2 years

(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)	
Complete Condition Report for Long-Life Guarantee	
Clutch: Change brake fluid; perform test and adaptation (Panamera S Hybrid)	

Every 4 years

(Labour operation 03 52 00 ..)

Replace tyre sealant	
----------------------	--

Signature (mechanic): _____

Test drive:

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: Check function	
Oils, fluids: Visual inspection for leaks	

Signature (final check): _____