

# PORSCHE

## Intermediate maintenance (China) Panamera / S / Turbo As of model year 2011

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Intermediate maintenance**

**at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 mls etc.  
(Labour operation 03 14 00 ..)**

For a description of the various models, see Technical Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓
---

<b>Electrics</b>	
Windscreen wiper/washer system, headlight washer: Check function and nozzle settings	
Horn: Check function	
Tyres and spare wheel: Check tyre pressure	
Diagnostic system: Read out fault memory; reset maintenance interval	
<b>Inside the vehicle</b>	
Particle filter: Replace filter element	
<b>Outside the vehicle</b>	
Check wiper blades	
All headlights: Check adjustment	
Clean reversing camera	
Battery vent hose: Check condition	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)	
<b>Under the vehicle</b>	
Drain engine oil, change oil filter	
Tyres and spare wheel: Check condition	
Brake lines: Visual inspection for damage, correct routing and corrosion	
Brake hoses: Visual inspection for damage	
Brake system: Visual inspection of brake pads and brake discs for wear	
Drive shafts: Visual inspection of the boots for leaks and damage	
Radiators and air intakes: Visual inspection for external soiling and blockage	
<b>Engine compartment</b>	
Top up engine oil	
Coolant: Check level and antifreeze	
Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season; use Porsche approved windscreen cleaner only	
PDCC and power steering: Check fluid level	
Throttle housing: clean inside	

Continued overleaf

# PORSCHE

## Intermediate maintenance (China) Panamera / S / Turbo As of model year 2011

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Additional maintenance, replacing spark plugs**  
(Labour operation 03 81 00 ..)

✓

Replace spark plugs on the Panamera	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs on the Panamera S	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs on the Panamera Turbo	every 20,000 km/12,000 mls or every 4 years	

**Additional maintenance every 90,000 km/54,000 mls**  
(Labour operation 03 83 00 ..)

Replace PDCC reservoir	every 90,000 km/54,000 mls or every 6 years	
PDK transmission: Change oil	every 90,000 km/54,000 mls or every 6 years	
Air cleaner: Replace filter element	every 90,000 km/54,000 mls or every 4 years	

**Additional maintenance every 180,000 km/108,000 mls or every 12 years**  
(Labour operation 03 88 00 ..)

Manual transmission: Change oil		
All-wheel final drive: Change oil		
Rear final drive: Change oil		

**Every 2 years**  
(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)		
Complete Condition Report for Long-Life Guarantee		

**Every 4 years**  
(Labour operation 03 52 00 ..)

Replace tyre sealant		
----------------------	--	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: Check function	
Oils, fluids: Visual inspection for leaks	

Signature (final check): \_\_\_\_\_