

# PORSCHE

## Maintenance (C markets\*) Panamera / S / GTS / Turbo / Diesel / S Hybrid As of model year 2012

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Maintenance**

at 60,000, 120,000, 180,000, 240,000 km/36,000, 72,000, 108,000, 144,000 mls etc.  
(Labour operation 03 16 00 ..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

**Note:** If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓
---

<b>Electrics</b>	
Windscreen wiper/washer system, headlight washer: Check function and nozzle settings	
Horn: Check function	
Tyres and spare wheel: Check tyre pressure	
Diagnostic system: Read out fault memory; reset maintenance interval; Read out soot mass particle filter (Panamera Diesel only)	
<b>Inside the vehicle</b>	
Seat belts: Check function and condition	
Particle filter: Replace filter element	
<b>Outside the vehicle</b>	
Check wiper blades	
All headlights: Check adjustment	
Clean reversing camera	
Trailer hitch: Check function	
Battery vent hose: Check condition	
Tyres and spare wheel: Check condition	
Brake system: Visual inspection of brake pads and brake discs for wear	
Brake hoses: Visual inspection for damage	
Radiators and air intakes: Visual inspection for external soiling and blockage	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89) **	
<b>Under the vehicle</b>	
Underbody panels: Visual inspection for completeness, secure installation and damage	
Drain engine oil, change oil filter (observe oil change service plan)	
Replace fuel filter (Panamera Diesel only)	
Visual inspection for leaks (oils and other fluids)	
Brake lines: Visual inspection for damage, correct routing and corrosion	
Steering gear: Visual inspection of the bellows for damage	
Tie rod joints: Check the play and dust bellows	
Drive shafts: Visual inspection of the boots for leaks and damage	
Axle joints: Check the play and visually inspect the dust bellows for damage	
Exhaust system: Visual inspection for leaks and damage, check engine mounts	
<b>Engine compartment</b>	
Top up engine oil (observe oil change service plan)	
Fuel lines and connections: Visual inspection	
Visual inspection for leaks (oils and other fluids)	
Coolant: Check level and antifreeze	
Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season; use Porsche approved windscreen cleaner only	
PDCC and power steering: Check fluid level	
Throttle housing: clean inside**	

\* For country allocation, see overview of A, B and C markets

\*\* Applies only for China

Continued overleaf

# PORSCHE

## Maintenance (C markets) Panamera / S / GTS / Turbo / Diesel / S Hybrid As of model year 2012

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Additional maintenance, replacing spark plugs**  
(Labour operation 03 81 00 ..)

		✓
Replace spark plugs - Panamera	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs - Panamera S / GTS	every 30,000 km/18,000 mls or every 4 years	
Replace spark plugs - Panamera Turbo	every 20,000 km/12,000 mls or every 4 years	
Replace spark plugs - Panamera S Hybrid	every 20,000 km/12,000 mls or every 4 years	

**Additional maintenance every 90,000 km/54,000 mls or every 4 years**  
(Labour operation 03 83 00 ..)

Replace PDCC reservoir		
PDK transmission: Change oil (Panamera / S / GTS / Turbo)		
Turbo compressor: Replace drive belt (Panamera S Hybrid)		
Air cleaner: Replace filter element (Panamera / S / Turbo / S Hybrid)		
Air cleaner/additional air filter: replace filter elements (Panamera GTS)		

**Additional maintenance every 180,000 km/108,000 mls or every 12 years**  
(Labour operation 03 88 00 ..)

Manual transmission: Change oil		
All-wheel final drive: Change oil		
Rear final drive: Change oil		

**Additional maintenance every 240,000 km/144,000 mls or every 16 years**  
(Labour operation 03 95 00 ..)

Automatic transmission: change ATF and ATF filter (Panamera Diesel / S Hybrid)		
--	--	--

**Every 2 years**  
(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)		
Complete Condition Report for Long-Life Guarantee		
Clutch: Change brake fluid; perform test and adaptation (Panamera S Hybrid)		

**Every 4 years**  
(Labour operation 03 52 00 ..)

Replace tyre sealant		
----------------------	--	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: Check function		
Oils, fluids: Visual inspection for leaks		

Signature (final check): \_\_\_\_\_