

PORSCHE

Maintenance (China) Panamera / S / Turbo As of model year 2011

Working instruction
for order no.

| |
|--|
| |
|--|

Vehicle Ident. No. _____

Maintenance

at 60,000, 120,000, 180,000, 240,000 km/36,000, 72,000, 108,000, 144,000 mls etc.

(Labour operation 03 16 00 ..)

For a description of the various models, see Technical Manual

Note: If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓

| | |
|---|--|
| Electrics | |
| Windscreen wiper/washer system, headlight washer: Check function and nozzle settings | |
| Horn: Check function | |
| Tyres and spare wheel: Check tyre pressure | |
| Diagnostic system: Read out fault memory; reset maintenance interval | |
| Inside the vehicle | |
| Seat belts: Check function and condition | |
| Particle filter: Replace filter element | |
| Outside the vehicle | |
| Check wiper blades | |
| All headlights: Check adjustment | |
| Clean reversing camera | |
| Trailer hitch: Check function | |
| Battery vent hose: Check condition | |
| Tyres and spare wheel: Check condition | |
| Brake system: Visual inspection of brake pads and brake discs for wear | |
| Brake hoses: Visual inspection for damage | |
| Radiators and air intakes: Visual inspection for external soiling and blockage | |
| Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89) | |
| Under the vehicle | |
| Underbody panels: Visual inspection for completeness, secure installation and damage | |
| Drain engine oil, change oil filter | |
| Visual inspection for leaks (oils and other fluids) | |
| Brake lines: Visual inspection for damage, correct routing and corrosion | |
| Steering gear: Visual inspection of the bellows for damage | |
| Tie rod joints: Check the play and dust bellows | |
| Drive shafts: Visual inspection of the boots for leaks and damage | |
| Axle joints: Check the play and visually inspect the dust bellows for damage | |
| Exhaust system: Visual inspection for leaks and damage, check engine mounts | |
| Engine compartment | |
| Top up engine oil | |
| Fuel lines and connections: Visual inspection | |
| Visual inspection for leaks (oils and other fluids) | |
| Coolant: Check level and antifreeze | |
| Windscreen wiper/washer system: Check fluid level; check window cleaner and antifreeze, depending on the season; use Porsche approved windscreen cleaner only | |
| PDCC and power steering: Check fluid level | |
| Throttle housing: clean inside | |

Continued overleaf

PORSCHE

Maintenance (China) Panamera / S / Turbo As of model year 2011

Vehicle Ident. No. _____

Working instruction
for order no.

| |
|--|
| |
|--|

Additional maintenance, replacing spark plugs
(Labour operation 03 81 00 ..)

| | | |
|---|---|---|
| | | ✓ |
| Replace spark plugs on the Panamera | every 30,000 km/18,000 mls or every 4 years | |
| Replace spark plugs on the Panamera S | every 30,000 km/18,000 mls or every 4 years | |
| Replace spark plugs on the Panamera Turbo | every 20,000 km/12,000 mls or every 4 years | |

Additional maintenance every 90,000 km/54,000 mls
(Labour operation 03 83 00 ..)

| | | |
|-------------------------------------|---|--|
| | | |
| Replace PDCC reservoir | every 90,000 km/54,000 mls or every 6 years | |
| PDK transmission: Change oil | every 90,000 km/54,000 mls or every 6 years | |
| Air cleaner: Replace filter element | every 90,000 km/54,000 mls or every 4 years | |

Additional maintenance every 180,000 km/108,000 mls or every 12 years
(Labour operation 03 88 00 ..)

| | | |
|-----------------------------------|--|--|
| | | |
| Manual transmission: Change oil | | |
| All-wheel final drive: Change oil | | |
| Rear final drive: Change oil | | |

Every 2 years
(Labour operation 03 51 00 ..)

| | | |
|--|--|--|
| | | |
| Change brake fluid (use only original Porsche brake fluid) | | |
| Complete Condition Report for Long-Life Guarantee | | |

Every 4 years
(Labour operation 03 52 00 ..)

| | | |
|----------------------|--|--|
| Replace tyre sealant | | |
|----------------------|--|--|

Signature (mechanic): _____

Test drive:

| | | |
|--|--|--|
| Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: Check function | | |
| Oils, fluids: Visual inspection for leaks | | |

Signature (final check): _____