

PORSCHE

Maintenance (China) Panamera S/Turbo As of 2010 model

Work instruction for
order no.

Vehicle identification no. _____

Maintenance

Every 60,000, 120,000, 180,000, 240,000 km/36,000, 72,000, 108,000, 144,000 mls etc.
(Labour operation 03 16 00 ..)

For a description of the various models, see Technical Manual

Note: if the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term 'checking' includes all necessary subsequent work such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.



Electrics	
Windscreen wiper/washer system, headlight cleaning system: check operation and nozzle settings	
Horn: check operation	
Tyres and spare wheel: check tyre pressure	
Diagnosis system: read out fault memory; reset maintenance interval	
Inside the vehicle	
Seat belts: check function and condition	
Particle filter: replace filter element	
Outside the vehicle	
check wiper blades	
All headlights: check adjustment	
Clean reversing camera	
Trailer hitch: check operation	
Battery vent hose: check condition	
Tyres and spare wheel: check condition	
Brake system: visual inspection of brake pads and discs for wear	
Brake hoses: visual inspection for damage	
Radiators and air inlets: visual inspection for external contamination and blockage	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)	
Under the vehicle	
Vehicle underbody: visual inspection for leaks (oils and other fluids); underbody covers: visual inspection for completeness, Drain engine oil, replace oil filter	
visual inspection for leaks (oils and other fluids)	
Brake lines: visual inspection for damage, routing and corrosion	
Steering gear: visually inspect the bellows for damage	
Tie rod joints: check the play and dust boots	
Drive shafts: visual inspection of the boots for leaks and damage	
Axle joints: check the play and visually inspect the dust boots for damage	
Exhaust system: visual inspection for leaks and damage, check engine mount	
Engine compartment	
Top up engine oil	
Fuel lines and connections: visual inspection	
visual inspection for leaks (oils and other fluids)	
Coolant: check level and antifreeze	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on the season, use Porsche approved windscreen cleaner only	
PDCC and power steering: check fluid level	

Continued overleaf

PORSCHE

Maintenance (China) Panamera S/Turbo As of 2010 model

Vehicle identification no. _____

Work instruction for
order no.

--

Additional maintenance, replace spark plugs

(Labour operation 03 81 00 ..)



Replace spark plugs on Panamera S	every 30,000 km/18,000 miles or every 4 years	
Replace spark plugs on Panamera Turbo	Every 20,000 km/12,000 miles or every 4 years	

Additional maintenance every 90,000 km/54,000 mls

(Labour operation 03 83 00 ..)

Replace PDCC reservoir	Every 90,000 km/54,000 miles or every 6 years	
PDK transmission: change oil	Every 90,000 km/54,000 miles or every 6 years	
Air cleaner: replace filter element	Every 90,000 km/54,000 miles or every 4 years	

Additional maintenance every 180,000 km/108,000 miles or every 12 years

(Labour operation 03 88 00 ..)

Manual transmission: change oil		
All-wheel final drive: change oil		
Rear final drive: change oil		

Every 2 years

(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)		
Prepare condition report for long-life guarantee		

Every 4 years

(Labour operation 03 52 00 ..)

Replace tyre sealant		
----------------------	--	--

Signature (mechanic): _____

Test drive:

Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, air conditioning and instruments: check operation		
Oils, fluids: visual inspection for leaks		

Signature (final check): _____