

PORSCHE

Minor maintenance (China) 911 Turbo (997) as of 2009 model

Vehicle Ident. No. _____

Working instruction
for order no.

--

Intermediate maintenance

at 30,000, 90,000, 150,000, 210,000 km etc./18,000, 54,000, 90,000, 126,000 miles etc.

(Labour operation 03 14 00 ..)

For a description of the various models, see Technical Manual

Note: If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

	✓
Mix fuel in the tank with additive (Keropur from Porsche; Part No. 000 043 206 89) and check and if necessary affix additional Chinese sticker relating to fuel quality on the tank cap	
Diagnostic system: read out fault memory; reset maintenance interval	
Change engine oil and oil filter (please observe oil change service plan for the 911 Turbo)	
Vehicle underbody and engine compartment: visual inspection for leaks (oils and fluids) and chafing damage (lines and hoses) Underbody panels: visual inspection for completeness, secure installation and damage	
Coolant hoses: check condition Radiators and air inlets: visual inspection for external contamination and blockage Coolant: check level and antifreeze	
Particle filter: replace filter element	
Brake system: visual inspection of brake pads and brake discs for wear (without removing and fitting wheels)	
Brake hoses and lines: visual inspection for leaks, damage, routing and corrosion	
Drive shafts: visual inspection of the boots for leaks and damage	
Tyres: check condition and tyre pressure	
Check the door locks, lid locks and safety hooks of the front lid to ensure that they are secure and functioning properly	
Vehicle lighting: check operation All headlights: check adjustment Horn: check operation	
Windscreen wiper/washer system, headlight cleaning system: check fluid level and nozzle settings, check antifreeze in winter months; check wiper blades	
Electrical equipment, warning and indicator lights: check operation	
Battery: check functional state and fluid level	
Replace spark plugs: see Additional maintenance	

Continued overleaf

PORSCHE

Intermediate maintenance (China) 911 Turbo (997) as of 2009 model

Vehicle Ident. No. _____

Working instruction
for order no.

--

Additional maintenance for spark plugs
(Labour operation 03 81 00 ..)

911 Turbo	every 20,000 km/12,000 miles or every 4 years	<input checked="" type="checkbox"/>
-----------	---	-------------------------------------

Additional maintenance for drive belt
(Labour operation 03 60 00 ..)

Check drive belt	every 60,000 km/36,000 miles or every 4 years	<input type="checkbox"/>
Check drive belt	every 150,000 km/90,000 miles or every 10 years	<input type="checkbox"/>
Check drive belt	every 240,000 km/144,000 miles or every 16 years	<input type="checkbox"/>

Additional maintenance for convertible top
(Labour operation 03 70 00 ..)

Service and maintain convertible top	every 30,000 km/18,000 miles or every 2 years	<input type="checkbox"/>
--------------------------------------	---	--------------------------

Additional maintenance every 90,000 km/54,000 miles or every 6 years
(Labour operation 03 83 00 ..)

Replace drive belt		<input type="checkbox"/>
Replace fuel filter (911 Turbo only)		<input type="checkbox"/>
Controlled all-wheel drive (911 Turbo): change oil		<input type="checkbox"/>

Additional maintenance every 180,000 km/108,000 miles or every 12 years
(Labour operation 03 88 00 ..)

Manual transmission: change oil		<input type="checkbox"/>
Automatic transmission: change ATF and ATF filter		<input type="checkbox"/>
Automatic transmission: change oil in final drive		<input type="checkbox"/>
All-wheel final drive: change oil		<input type="checkbox"/>

Every 2 years

File condition report for long-life guarantee		<input type="checkbox"/>
Change brake fluid		<input type="checkbox"/>

Every 4 years

Replace tyre sealant		<input type="checkbox"/>
----------------------	--	--------------------------

After 4 years, then every 2 years

Check tyre pressure monitoring system battery		<input type="checkbox"/>
---	--	--------------------------

After 4, 8, 10 years, then every 2 years

Ancillary unit mounts and suspension: visual inspection of all rubber mountings and boots for damage		<input type="checkbox"/>
--	--	--------------------------

Signature (fitter): _____

Test drive:

Remote control, front seats, footbrake and handbrake (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, PASM switch, Sport switch, heating, air conditioning and instruments: check operation		<input type="checkbox"/>
Oils, fluids: visual inspection for leaks		<input type="checkbox"/>

Signature (final check): _____